

Hochlastzeitfenster für das Jahr 2013 für die Spannungs- bzw. Umspannebene MS (Datenbasis 2011 / 2012)

	1/4-Intervall			6:00	6:15	6:30	6:45	7:00	7:15	7:30	7:45	8:00	8:15	8:30	8:45	9:00	9:15	9:30	9:45	10:00	10:15	10:30	10:45	11:00	11:15	11:30	11:45	12:00	12:15	12:30	12:45	13:00	13:15	13:30	13:45	14:00	14:15	14:30	14:45	15:00	15:15	15:30	15:45	16:00	16:15	16:30	16:45	17:00	17:15	17:30	17:45	18:00	18:15	18:30	18:45	19:00	19:15	19:30	19:45	20:00	20:15	20:30	20:45	21:00	21:15	21:30	21:45	22:00	22:15	22:30	22:45	23:00	23:15	23:30	23:45
	Hochlastzeit 1	Hochlastzeit 2	Hochlastzeit 3																																																																								
Herbst	8:30 - 9:45	10:15 - 10:30	11:00 - 12:45																																																																								
Winter	8:15 - 13:15																																																																										
Frühling	8:30 - 9:45	11:00 - 12:45																																																																									
Sommer																																																																											

Jahreszeiten:

Herbst 01.09.2013 - 30.11.2013
 Winter 01.01.2013 - 28.02.2013 und 01.12.2013 - 31.12.2013
 Frühling 01.03.2013 - 31.05.2013
 Sommer 01.06.2013 - 31.08.2013